



Custom White Balance Checklist

Nikon Z6III

RevScottPhoto — How Would You Shoot This?

Steps

- ☐ 1. Press and hold Fn1. On this body, Fn1 is set up to control white balance.
- ☐ 2. While still holding Fn1, rotate the command dial to select PRE, and the sub-command dial to choose a preset slot, d-1 through d-6.
- ☐ 3. Press OK. This switches the menu to Measure.
- ☐ 4. Fill the frame with a neutral white or gray card under the target light and press the shutter release.
- ☐ 5. Watch for the data acquired message to confirm success. If it fails, repeat from step 3.
- ☐ 6. Press the eye sensor/viewfinder button to get back to normal shooting view.

Notes

Field tested method. If Fn1 is ever reassigned to something else, use the full menu path instead: Photo Shooting Menu > White balance > PRE manual preset > choose d-slot > Measure.

Preset Slot Log

Track which preset slot (d-1 to d-6) you used at each venue so you can reuse it next time.

Date	Venue / Gym	Light Type	Slot (d-#)	Notes